

#### Contact us

Tel: +44 (0) 1684 273164

Email: enquiry@ingridwest.co.uk

## FEEDER HEAD OPTIONS


### MULTI WIRE AND TAPE FEEDER HEAD

- Used for producing multi-winding transformers at one workstation
- Allows use of up to 4 different wire sizes without rethreading
- Felt pads for cleaning of wire and back tension
- Includes margin tape and cover tape attachment




### GUIDE TUBE FEEDER HEAD

- Ceramic parts at every wire contact point, to protect the wire coating
- Guide tube places wire accurately
- Independent micro-adjustment for more than one spindle
- Felt pad for cleaning of wire and back tension
- Takes guide tubes of inside diameter 0.3-1.2 mm




### FIXED ROLLER FEEDER HEAD WITH MICRO ADJUSTMENT

- Durable brass rollers to control heavy gauge wire
- Independent micro-adjustment for more than one spindle
- Felt pad for cleaning of wire and back tension



### VARIABLE ANGLE ROLLER FEEDER HEAD

- Durable brass rollers to control heavy gauge wire
- Adjustable angle of feed
- Adjustable roller position enables wire pre-bend/straightening



We aim to be much more than a machinery supplier. Our team has a vast range of winding experience and is able to offer help and advice on all aspects of coil winding, from tooling design to machine choice and set-up.

## COIL WINDING SOLUTIONS YOU CAN RELY ON

WORKING WITH LOCAL PARTNERS IN THE FOLLOWING COUNTRIES; Austria, Czech Republic, Germany, Hungary, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden.

Unit 5L, Delta Drive, Tewkesbury, Glos. GL20 8HB. United Kingdom.

